

KISS® SOFT EDGE



SUPERIOR SUSPENSION SLEEVE PROTECTION AT THE PROXIMAL SOCKET EDGE



INSTRUCTIONS

- USE FINE SAND PAPER TO LIGHTLY ABRABE THE SOCKET TRIM EDGE
- UNROLL THE KISS® SOFT EDGE, CUT TO DESIRED LENGTH, AND STAPLE OR APPLY A WEIGHT TO BOTH ENDS
- APPLY 2 COATS OF CONTACT CEMENT TO THE SOCKET EDGE AND THE KISS® SOFT EDGE BACKING (NON PLUSH SIDE)
- APPLY WHILE LIGHTLY STRETCHING FOR EASY CONTOURING

For More Information Call: 410-663-KISS (5477)

www.kiss-suspension.com